

Experiment 14: Packet Sniffing using RAW Sockets

AIM:

To implement a **packet sniffer** using RAW sockets with Python and Scapy to capture and display **IP packets** along with their protocol type, source IP, and destination IP.

CODE:

```
from scapy.all import sniff  
from scapy.layers.inet import IP, TCP, UDP, ICMP
```

```
def packet_callback(packet):  
    if IP in packet:  
        ip_layer = packet[IP]  
        protocol = ip_layer.proto  
        src_ip = ip_layer.src  
        dst_ip = ip_layer.dst  
  
        # Determine the protocol  
        if protocol == 1:  
            protocol_name = "ICMP"  
        elif protocol == 6:  
            protocol_name = "TCP"  
        elif protocol == 17:  
            protocol_name = "UDP"  
        else:  
            protocol_name = "Unknown Protocol"  
  
        # Print packet details  
        print(f"Protocol: {protocol_name}")  
        print(f"Source IP: {src_ip}")  
        print(f"Destination IP: {dst_ip}")  
        print("-" * 50)
```

```
# Capture packets on the default network interface  
sniff(iface='Wi-Fi', prn=packet_callback, filter="ip", store=0)
```

SAMPLE OUTPUT:

Protocol: TCP

Source IP: 192.168.1.10

Destination IP: 142.250.72.14

Protocol: ICMP

Source IP: 192.168.1.10

Destination IP: 8.8.8.8

Protocol: UDP

Source IP: 192.168.1.10

Destination IP: 192.168.1.1

RESULT:

The packet sniffer successfully captured **IP packets** on the network, identifying their **protocol type, source IP, and destination IP**.

This demonstrates the use of **RAW sockets** for monitoring network traffic in real-time.