

## Practical-4 Packet Sniffing using RAW Sockets

Aim:

To implement a "packet sniffer" using RAW sockets with Python & Scapy to capture & display IP packets along with their protocol type, source IP & destination IP.

Code:

```
from scapy.all import sniff
from scapy.layers.inet import IP,TCP,UDP,ICMP

def Packet_callback(Packet):
    if IP in Packet:
        ip_layer = packet[IP]
        Protocol = ip_layer.proto
        SrcIP = ip_layer.src
        dst_ip = ip_layer.dst

        if Protocol == 1:
            Protocol_name = "ICMP"
        elif Protocol == 6:
            Protocol_name = "TCP"
        elif Protocol == 17:
            Protocol_name = "UDP"
        else:
            Protocol_name = "Unknown Protocol"

        print(f"Protocol : {Protocol_name}")
        print(f"Source IP : {src_ip}")
        print(f"Destination IP : {dst_ip}")
        print("-" * 50)

    sniff(iface = 'Wi-Fi', prn = Packet_callback,
          filter = "ip", store = 0)
```

Result:

The packet sniffer successfully captured IP packets on the network, identifying their protocol type, source IP & destination IP.